



TO: ALL AUTHORIZED SERVICE ACCOUNTS
AS-1975 MANUAL OWNERS

SUBJECT: FORD 1998 PATS II KEY INTRODUCTION

NO: AS-1158
DATE: 3-31-98
FILE IN: BULLETIN BINDER

Must have 2 Pre-programmed PATS Keys

1. Cut the correct mechanical code on to a PATS key blank.
2. Insert the first programmed key into the ignition and turn from OFF to RUN. Leave in the RUN position for one (1) second.
3. Turn ignition to the OFF position, and remove the first key.
4. Within five (5) seconds, insert the second programmed key into the ignition and turn from OFF to RUN. Leave in the RUN position for one (1) second.
5. Turn ignition to the OFF position, and remove the second key.
6. Within ten (10) seconds, insert the unprogrammed key into the ignition and turn from OFF to RUN. Leave in the RUN position for one (1) second.
7. Repeat this process for additional keys.