



ONBOARD PROGRAMMING FOR THE REMOTE PORTION:

1. Insert key into ignition, do not turn on.
2. Short Pins 1 and 4 in the OBD2 Port.
3. Within 10 Seconds of shorting the pins push the Hazzard Switch six times. The door locks will cycle.
4. Push the lock button on the first remote three times within 10 seconds. The door locks will cycle if the remote was recognized.
5. Follow this same step for any additional remotes.
6. Remove the short on Pins 1 and 4 on the OBD2 Connector.
7. Remove the Key from the Ignition.
8. Test all remotes.