

ON-BOARD PROGRAMMING

ON-BOARD
PROGRAM

21

TOYOTA 1999-2007



CAMRY 2000-2001, SIENNA 1999-2003,
SOLARA 1999-2003, 4RUNNER 1999-2002,
SEQUOIA 2003-2007

1. Start with key out of ignition, driver's door is open all others closed and driver's door is unlocked.
2. Insert key into the ignition (Do NOT Turn) and Pull key out.
3. Perform these steps within 40 seconds.
 - a. Using the power lock switch on the driver's door, perform 5 lock/unlock cycles starting with lock. Use an even pace and try to go about one cycle per second (1 Cycle = 1 lock and 1 unlock).
 - b. Close, then open driver's door.
4. Perform these steps within 40 seconds.
 - a. Using the power lock switch on the driver's door, perform 5 lock/unlock cycles starting with lock. Use an even pace and try to go about one cycle per second (1 Cycle = 1 lock and 1 unlock).
 - b. Insert the key in the ignition cylinder.
 - c. Turn the ignition to ON (Do NOT Start) then back to OFF once to program remote while retaining the original remote codes. Twice to erase all original codes and add new remote. Three times to check how many remotes are programmed or five times to erase all original codes.
 - d. Remove the key from the ignition.
5. Within 3 seconds the power door locks should cycle automatically indicating successful entry into programming mode. Return to step 1 if the locks do not cycle at this point.
6. Perform these steps within 40 seconds.
 - a. Press the lock and unlock buttons on the remote simultaneously for 1 second.
 - b. Immediately after letting go of the lock and unlock buttons, press the lock button itself and hold for 2 seconds. Within 3 seconds, the door locks should cycle once indicating successful programming. If the door locks do not cycle, or cycle twice. Repeat steps A and B in step 6 as your remote has not been accepted.
 - c. Repeat steps A and B in step 6 for each new remote.
7. Close driver's door.