



Keys can be programmed using the Code-Seeker on most 32 bit systems. The 2003-2007 Sequoia requires flashing.

### **TO DELETE ALL BUT ONE KEY FROM THE UNIT:**

1. Simultaneously depress and release brake and accelerator pedals 1 time.
2. Insert an existing master key into the ignition cylinder. Do not turn the key from the OFF (LOCK) position.
3. Within fifteen seconds of inserting the key, depress and release the accelerator pedal six times.
4. Within twenty seconds of completing the above step, depress and release the brake seven times.
5. The security light will flash, indicating all keys other than the one being used have been deleted.
6. Remove the key from the ignition cylinder within ten seconds. It will be the only key still programmed to work.

### **ADD DUPLICATE KEY:**

Requires one working Toyota/Lexus Master key.

1. Make sure all doors and windows are closed.
2. Insert Master key into the ignition cylinder.
3. Cycle the ignition cylinder from ON to OFF five times.
4. Open and close the driver side door six times.
5. Remove the Master key and insert the new duplicate key.
6. TURN THE IGNITION CYLINDER ON.
7. The new key will be registered after 60 seconds. The THEFT light on the dashboard will go out, indicating that the programming has been completed.